



## MCB group sizes SNEP<sup>®</sup> MODE X

	Length [mm]	Power	Control	C10	C13	C16	B10	B13	B16
X04	1170	HE	On/Off	27	35	44	16	21	26
X04	1170	HE	DALI	21	28	36	13	17	22
X04	1170	HE	Industrial ON/OFF	26	34	42	20	25	32
X04	1170	HE	Industrial DALI	14	20	24	7	10	12
X04	1170	HO	On/Off	16	21	26	9	12	15
X04	1170	HO	DALI	18	24	30	11	14	18
X04	1170	HO	Industrial ON/OFF	26	34	42	20	25	32
X04	1170	HO	Industrial DALI	14	19	23	10	12	16
X04	1170	XO	On/Off	13	17	22	8	10	13
X04	1170	XO	DALI	13	17	21	7	10	12
X04	1170	XO	Industrial ON/OFF	18	24	30	11	14	18
X04	1170	XO	Industrial DALI	14	19	23	10	12	16
X04	1170	XT	Industrial ON/OFF	13	17	20	11	14	18
X04	1170	XT	Industrial DALI	13	17	20	10	12	16
X06	1730	HE	On/Off	18	24	30	11	14	18
X06	1730	HE	DALI	19	25	31	11	14	18
X06	1730	HE	Industrial ON/OFF	18	24	30	11	14	18
X06	1730	HE	Industrial DALI	18	24	30	11	14	18
X06	1730	HO	On/Off	13	17	22	8	10	13
X06	1730	HO	DALI	13	17	21	7	10	12
X06	1730	HO	Industrial ON/OFF	18	24	30	11	14	18
X06	1730	HO	Industrial DALI	14	19	23	10	12	16
X06	1730	XO	On/Off	11	15	19	7	9	11
X06	1730	XO	DALI	12	16	20	7	9	12
X06	1730	XO	Industrial ON/OFF	18	24	30	11	14	18
X06	1730	XO	Industrial DALI	14	19	23	10	12	16
X06	1730	XT	Industrial ON/OFF	13	17	20	11	14	18
X06	1730	XT	Industrial DALI	13	17	20	10	12	16

The announced circuit breaker group sizes are presenting the lower value from the inrush current and continuous load values. When designing actual group sizes one need to take into account at least the following: cabling, MCB installation environment and the loading of the MCB. Purso Oy is not responsible for the actual group sizes.